

MCG0006 Tabletop Easel Assembly

Instructions:

1. Open the carton and remove the Tabletop Easel onto a work surface. *Do not open out the base yet.*
2. Unscrew the Wingnut and Bolt that holds the canvas support onto the mast.
3. The base and mast should now be two separate pieces.
4. Flip the easel support around and with the 'shelf' facing out slide it back into the frame from the top down.
5. Once in place, fix the easel support to the mast using the Wingnut and Bolt. Tighten the Wingnuts on the sides to hold the mast in position.

Now your Tabletop Easel is ready to use!

